


INSTRUCTION MANUAL



FOR AUTOMATIC VOTING MACHINES

WITH AMERICAN LOCKER LOCKS — FOUR KEY COMBINATION —



AUTOMATIC VOTING MACHINE DIVISION · JAMESTOWN, N.Y.

CONTENTS

- SECTION A Keys and Use
Pages 1 and 2, 5 and 7 - Instructions for All Machines.
Raising and opening the machine. To insert Ballot Labels. Lock out unused Voting Pointers.
Pages 3 and 4 (to unlock and open the rear of the machine) - Instructions for Regular machines only.
- SECTION B Instructions for All Machines.
Disconnecting Individual Voting Pointers from Party Lever.
Inserting Party Lever Ballot Labels.
- SECTION C Instruction for All Machines.
Pages 1 thru 3 - Single Write-In Machines – 3 thru 5 - Double Write-In Machines.
Arranging the Interlocking Channel. Adjusting the Paper Roll. Installing a new Paper Roll.
- SECTION D Instructions for All Machines.
Attaching the Endorsing Mechanism.
- SECTION E Instructions for All Machines.
To attach and adjust the "Single Shot" Device
- SECTION F Instructions for All Machines.
Preparing the machine for a Primary Election. To connect Individual Voting Pointers to the Primary Mechanism (Disconnecting Pins).
- SECTION G Instructions for All Machines.
Preparing the machine for Secret Primary Election. To connect Individual Voting Pointers to the Primary Mechanism (Disconnecting Pins). Non-Partisan Election occurring at a Secret Primary Election. The use of the Paper Roll at a Secret Primary Election.
- SECTION H Pages 1 thru 4 - Instructions for Regular Machines only.
Pages 5 thru 10 - Instructions for All Machines.
Resetting Candidate and Public Counters. Closing and locking machine. Setting After Election Latch. Preparing machine for Restricted Question Voting, Preparing the machine for Restricted Office Voting.
Locks, Latches and Lockouts used on machines.
- SECTION I Instructions for All Machines.
Electrically operated machines.

CONTENTS (cont'd)

- SECTION J Page 1 - Instructions for Regular Machines only.
 Printing Ballot Labels, RReturn Sheets and Sample Ballots.
 Page 2 - Instructions for All Machines.
 General Directions and Specifications.
 Pages 3 and 4 - Instructions for PRINTOMATIC Machines.
 Printing Ballot Labels, Printed Return Sheet Packs, and Sample Ballots.
- SECTION K Instructions for PRINTOMATIC Machines only.
 Place PRINTOMATIC machine in voting position. Reset Counters.
 Load Return Sheet Packs. Close and lock machines.
 Set After Election Latch.

NOTE:

The sections of this manual have been arranged in the order in which a machine is ordinarily prepared for an election. If a section is missing from your manual it is because the information contained therein is not required under the election laws of your state.

NOTICE TO CUSTODIANS


The instructions contained in this manual are designed to cover the requirements for preparing voting machines in your state. If you wish additional or more detailed information, write to the Automatic Voting Machine Division, AVM Corporation, Jamestown, New York.

Before the machine is prepared for an election, all the equipment used in any previous election should be removed. This includes old Ballot Labels and Voting Pointer Covers from the face of the machine, Compensators and any Auxiliary Mechanisms from the Interlocking Channel in the Custodians Compartment. After this has been done, preparations for the coming election can be made in accordance with the directions contained in this manual of instructions.


VOTING MACHINE KEYS AND THEIR USE
AMERICAN LOCKER LOCKS – FOUR KEY COMBINATION

Two complete sets of keys are supplied with each Automatic Voting Machine. A third complete set is retained by the factory. In the event that a replacement becomes necessary, you need only notify the factory as to the serial number of the machine concerned and the particular key desired. The set of keys retained by the factory will then be used as a guide in cutting the replacement keys.

Each key is clearly stamped with an identifying number or letter. Each complete set of keys for one machine is placed on key rings together with tags showing the serial number of the machine and indicating that the keys on that particular ring are for use by Election Officials or by the Custodian only. Each complete set of keys is placed on tagged key rings as follows:



Election Officials:
No. 2 Key
No. 3 Key



Custodian Only:
No. 4 Key
No. 0 Key



Custodian only:
No. 5 Key

NOTE: (Machines used in some communities are not equipped with a No.5 Lock and this key will, of course, not be found in those communities.)

IMPORTANT: All keys and locks on Automatic Voting Machines are designed to operate with light finger pressure. Do not use force in attempting to use keys since excessive force may result in a damaged or broken key. Before using key always make certain that you are using the right key for the right lock on the right machine.

